

Instructions for attaching the Builders Extensions – 1/2

Materials: 4 5/16" Nuts
4 Washers
2 Side stand legs

4 5/16" X 1" Carriage Bolts
1 Fences with rollers

1. Attach a fence extension to each side. The lip plate guard for the fence extension should be pointed toward the outside of the panel saw. Align the square holes on the edge of each fence and insert a 5/16" X 1" bolt through each of the two holes. Attach a washer and nut from the other side to each bolt. Align the fences along the top edge and tighten the nuts. See Figure 1.
2. On the outside end of each fence, attach a short side stand that would align with the fence and a short side stand that is angled back. Use the 1" bolt, with the head on the inside on the top hole and the 1" bolt with the head on the inside on the bottom of the fence.
3. Adjust as necessary the side stand legs to the floor height for even alignment of the fences. See Figure 2.

Figure 1.



Figure 2.

