



Model LXP01/LXP01Z/LXP01CW Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	
1	868980-4	LXP01 NAME PLATE	
2	188971-2	HOUSING SET (BLUE)	(LXP01/LXP01Z)
	188970-4	HOUSING SET (WHITE)	(LXP01CW)
C10	263005-3	RUBBER PIN 6	
D10		INC. 19	
3	266429-2	TAPPING SCREW 3X16	
4	125832-5	SPEED CHANGE LEVER ASSEMBLY	
C10	233438-6	COMPRESSION SPRING 4	
5	419250-0	F/R CHANGE LEVER	
6	650637-9	SWITCH	
7	620012-3	LED CIRCUIT	
8	643852-2	TERMINAL	
9	251468-5	- FLAT HEAD SCREW M6X22	
10	766008-1	KEYLESS DRILL CHUCK 13	
11	125848-0	GEAR ASSEMBLY	
12	638611-7	YORK UNIT	
13	619263-3	ARMATURE	
14	638494-5	BRUSH HOLDER COMPLETE	
15	CB440	CARBON BRUSH CB-440 195021-6	
16	263032-0	RUBBER PIN 4	
17	452205-2	REAR COVER	(LXP01/LXP01Z)
	452202-8	REAR COVER	(LXP01CW)
18	266429-2	TAPPING SCREW 3X16	
19	188971-2	HOUSING SET	(LXP01/LXP01Z)
	188970-4	HOUSING SET	(LXP01CW)
C10	263005-3	RUBBER PIN 6	
D10		INC. 2	
20	232182-2	LEAF SPRING	
21	689170-4	HEAT SINK	
22	911013-5	PAN HEAD SCREW M3X10	
23	891618-6	CAUTION LABEL	
24	424026-2	CUSHION	
A01	251314-2	+ SCREW M4X12	(LXP01/LXP01CW)
A02	346449-3	HOOK	(LXP01)
	346034-2	HOOK	(LXP01CW)
A03	784614-0	+ - BIT 2-45	(LXP01/LXP01CW)
A04	140756-4	PLASTIC CARRYING CASE COMPLETE	(LXP01)
	824953-7	PLASTIC CARRYING CASE	(LXP01CW)
C10	162302-3	LATCH	(LXP01/LXP01CW)
C20	324207-7	SHAFT	(LXP01/LXP01CW)
C30	451749-9	HANDLE	(LXP01/LXP01CW)
A05	450128-8	BATTERY COVER	(LXP01/LXP01CW)
A06	***DC18RA	DC18RA FAST CHARGER	(LXP01/LXP01CW)
A07	BL1830	BATTERY BL1830 SET	(LXP01)
	BL1815	BATTERY BL1815 SET	(LXP01CW)