



Parts List for DCG412B Type 1

Item Number	Part Number	Description	Qty Required
1	N115615	CLAMSHELL SET	1
2	652479-00SV	ARMATURE ASSEMBLY	1
3	330003-60	BEARING	2
4	623564-00	PINION	1
5	604484-00	NUT	1
6	631563-00	BOOT	1
7	N171820	BEARING SUPPORT	1
8	623617-00	FELT SEAL	1
9	640579-00	FAN BAFFLE	1
10	623580-00	BRG. RETAINER	1
11	658547-00SV	GEARCASE ASSY	1
12	625414-00	GEAR CASE COVER	1
13	623618-00	GASKET	1
14	330065-13	SCREW	4
15	385676-01	SCREW	4
16	N129056	BUTTON,LOCK-OFF	1
17	N135777	RATING PLATE	1
18	N137612	IDENT. LABEL	1
19	N138047	SWITCH VS	1
20	611202-00SV	MAGNET RING	1
21	N342329	GUARD	1
21	N342331	GUARD	1
21	397661-01	GUARD	1
21	643772-00	GUARD	1
22	631609-02	SCREW	1
23	633257-00SV	BACKING FLANGE	1
24	636226-00	NUT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DCG412B Type 1

Item Number	Part Number	Description	Qty Required
25	330019-25	SCREW,THD.FORM	2
26	330019-04	SCREW,PLASTITE	6
30	610126-00	BRUSH BOX	2
31	N135776	WARNING LABEL (SPA)	1
43	N102647	SPRING	1
44	N091479	MOUNT- SPRING	1
87	401680-00	WRENCH	1
88	N239381	SIDE HANDLE	1
92	633044-00	O-RING	1
93	633043-00	O-RING	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
856	651278-09	GRINDING WHEEL	1
862	624807-01	TOOL BAG	1
866	DCB200	BATTERY PACK	2
871	DCB101	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.