

Model 14RT300A



ITEM	DESCRIPTION	PART NO.
1	Handle	3751031
2	Switch Button - I	7414200
3	Switch Button - O	7414210
4	Cord Hook	3856430
5	Motor Cover Assembly	2432022
6	Screw 10 x 3/4" Trilobe, Twin Lead	1517699
7	Power unit Assembly	8121097
8	Float	3545000
9	Lid Latch	7444500
10	Lid Cage and Latch Assembly	1944742
11	Cartridge Filter	90350
12	Filter Retainer	3008000
13	Tank Assembly	1026797
14	Inlet Deflector	7413120
15	Rear Caster Dolly	7431031
16	Retainer	8565500
17	Caster Foot A	8568000
18	Caster Foot B	8568010
19	Caster	6771200
20	Screw 10 x 3/4" SL Hex Head	1503999
21	Disposable Filter Bag	9190510

* Replacement parts may differ from original equipment.

