



## Model XTP01Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	266130-9	TAPPING SCREW BIND PT 3X16	1	PC.
002	267071-2	FLAT WASHER 4	1	PC.
003	187098-5	HOUSING SET	1	SET
	D10	INC. 95		
004	643843-3	TERMINAL	1	PC.
005	346449-3	HOOK	1	PC.
006	251314-2	+ SCREW M4X12	1	PC.
007	266130-9	TAPPING SCREW BIND PT 3X16	4	PC.
008	419450-2	FRONT COVER	1	PC.
009	266130-9	TAPPING SCREW BIND PT 3X16	1	PC.
010	345704-0	UPPER PLATE	1	PC.
011	345703-2	RAIL	1	PC.
012	922112-8	HEX. SOCKET HEAD BOLT M4X10	2	PC.
013	324683-5	GUIDE BOLT	1	PC.
014	253762-1	FLAT WASHER 8	1	PC.
015	421962-3	SPRING HOLDER	1	PC.
016	233472-6	COMPRESSION SPRING 17	1	PC.
017	421962-3	SPRING HOLDER	1	PC.
018	345701-6	HAMMER	1	PC.
019	421956-8	CUSHION	1	PC.
020	253804-1	FLAT WASHER 6	1	PC.
021	266130-9	TAPPING SCREW BIND PT 3X16	1	PC.
022	318025-3	HOLDER	1	PC.
023	931302-2	HEX. NUT M6	1	PC.
024	345702-4	DRIVER	1	PC.
025	268157-5	PIN 4	1	PC.
026	168430-2	DRIVER GUIDE COVER	1	PC.
027	922102-1	HEX. SOCKET HEAD BOLT M4X6	2	PC.
028-1	135370-9	MAGAZINE ASSEMBLY	1	PC.
	D10	INC. 29-44,48-55,100,101		
029	922122-5	HEX.SOCKET HEAD BOLT M4X14	1	PC.
030	310173-4	DRIVER GUIDE	1	PC.
031	951054-9	SPRING PIN 3-10	2	PC.
032	345699-7	PUSHER	1	PC.
033	310176-8	STOPPER	1	PC.
034	233018-8	COMPRESSION SPRING 3	1	PC.
035	232229-2	LEAF SPRING	1	PC.
036	346239-4	NAIL STOPPER	3	PC.
037	233476-8	COMPRESSION SPRING 4	3	PC.
038	318024-5	MAGAZINE	1	PC.
039	922102-1	HEX. SOCKET HEAD BOLT M4X6	1	PC.
040	345696-3	SPACER	1	PC.
041	951001-0	SPRING PIN 2-8	1	PC.
042	318023-7	LOWER RAIL	1	PC.
043	452877-3	NAIL GUIDE HOLDER	1	PC.
044	143626-6	UPPER RAIL COMPLETE	1	PC.
	D10	INC. 45,46		
045	810310-5	CAUTION LABEL	1	PC.
046	807U60-7	CAUTION LABEL	1	PC.
048	911113-1	PAN HEAD SCREW M4X10	1	PC.
049	419443-9	SHOULDER PIN 5-7	1	PC.

050	233470-0	COMPRESSION SPRING 5	1 PC.
051	266177-3	HEX. SOCKET HEAD BOLT M3X10	2 PC.
052	419446-3	LEVER	1 PC.
053	233117-6	COMPRESSION SPRING 6	1 PC.
054	951066-2	SPRING PIN 3-18	1 PC.
055	419444-7	SLIDE DOOR CAP	1 PC.
056	268158-3	PIN 5	1 PC.
057	265040-7	+ PAN HEAD SCREW M3X4	1 PC.
058	345705-8	LOCK ARM	1 PC.
059	629910-8	DC MOTOR	1 PC.
060	267053-4	FLAT WASHER 12	1 PC.
061	227166-3	INTERNAL GEAR 69	1 PC.
062	232230-7	LEAF SPRING	2 PC.
063	221961-3	SPUR GEAR 27	3 PC.
064	154973-0	SPUR GEAR 7 COMPLETE	1 PC.
065	345773-1	ANTI BACK PLATE	1 PC.
066	154972-2	SPUR GEAR 55 COMPLETE	1 PC.
067	214060-8	PLANE BEARING 10	1 PC.
068	620073-3	LED CIRCUIT	1 PC.
069	419452-8	LIGHT SWITCH ARM	1 PC.
070	233032-4	COMPRESSION SPRING 2	1 PC.
071	651891-8	SWITCH V-15-3A6	2 PC.
072	256299-7	PIN 3	1 PC.
073	419453-6	LINK PLATE	1 PC.
074	231693-4	TORSION SPRING 4	1 PC.
075	419454-4	SAFETY TRIGGER	1 PC.
076	256299-7	PIN 3	1 PC.
077	188168-3	TRIGGER SET	1 PC.
	D10	INC. 78-83	
078	419451-0	TRIGGER	1 PC.
079	256771-9	PIN 2.5	1 PC.
080	257926-9	STOP RING E-2.0	2 PC.
081	345707-4	SWING ARM	1 PC.
082	231694-2	TORSION SPRING 3	1 PC.
083	231695-0	TORSION SPRING 3	1 PC.
084	233360-7	COMPRESSION SPRING 4	1 PC.
085	256176-3	PIN 2.5	1 PC.
086	256176-3	PIN 2.5	1 PC.
087	345706-6	GUIDE PLATE	1 PC.
088	231692-6	TORSION SPRING 4	1 PC.
089	168489-9	CAM BLOCK	1 PC.
090	233188-3	COMPRESSION SPRING 2.4	1 PC.
091	951001-0	SPRING PIN 2-8	1 PC.
092	324923-1	PUSH PIN	1 PC.
093	345708-2	SWITCH ARM	1 PC.
094	256176-3	PIN 2.5	1 PC.
095	187098-5	HOUSING SET	1 SET
	D10	INC. 3	
096	851P33-2	XTP01 NAME PLATE	1 PC.
097	911163-6	PAN HEAD SCREW M4X35	1 PC.
098	266130-9	TAPPING SCREW BIND PT 3X16	8 PC.
099	911123-8	PAN HEAD SCREW M4X14	2 PC.
100	233459-8	COMPRESSION SPRING 3	1 PC.
101	951054-9	SPRING PIN 3-10	1 PC.
A01	195246-2	SAFETY GOGGLE	1 PC.
A02	419525-7	NOSE ADAPTER	1 PC.
A03	783201-2	HEX. WRENCH 3	1 PC.