



Parts List for DCT411S1 Type 1

Item Number	Part Number	Description	Qty Required
1	N130093	LABEL SET	1
2	N118585	IDENT. LABEL	1
3	N081558	HANDLE ASSEMBLY	1
4	N081613	MONITOR ASSEMBLY	1
5	N080683	CABLE CAMERA	1
8	330015-00	NUT	2
8	N068674	BELT HOOK	1
856	N115242	ACCY PACK	1
861	N068612	KIT BOX	1
866	DCB120	BATTERY PACK	1
871	DCB100	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.