



Crankshaft & Camshaft Seal Tool Kit

Install & Remove all passenger car, light truck and SUV crankshaft & camshaft seals without damage

- Easily remove and install crankshaft and camshaft seals without damage
- Compact puller with unique extracting hooks engage seal for quick removal
- Interchangeable sleeves and mandrels allow easy installation of new seal
- Suits seals from 21.5mm - 64mm


Camshaft Seal Removal



1. Remove Pulley



2. Insert Seal Extracting Hooks



3. Attach Puller



4. Remove Seal

- Use vehicle crankshaft or camshaft bolt to evenly press new seal into position
- Use installation sleeves if added depth is required

Camshaft Seal Installation



1. Select Installer Plate Bush



2. Insert into Installer Plate



3. Select Mandrel to Match Seal



4. Engage and Tighten Bolt to Install Seal

Crankshaft Seal Removal



1. Remove Pulley



2. Insert Seal Extracting Hooks



3. Attach Puller



4. Remove Seal

- Provides coverage for light commercial and heavy duty vehicles that utilize crankshaft & camshaft seals from 21.5mm - 64mm

Crankshaft Seal Installation



1. Select Installer Plate Bush



2. Insert into Installer Plate



3. Select Mandrel to Match Seal



4. Engage and Tighten Bolt to Install Seal



PATENT PENDING

Part No: 70960

PRIVATE BRAND TOOLS
(AUSTRALIA) PTY LTD
A.B.N. 72 067 983 475

41 Moreton Street
Heathwood QLD 4110
Australia

Phone: +61 7 3278 8299
Fax: +61 7 3278 8399

Internet: www.pbtusa.com
Email: sales@pbtusa.com