


Knife Cutter Instructions

1. Using the 3 wing nuts, adjust the knife cutter to cut along the left side of the dust pan: between the peak and the horizontal support arm of the frame.

2. Using the wing nut that holds the knife on the knife cutter insert, move your knife forward till there is about a half an inch between the knife and the surface of the material you are cutting.



3. Adjust the blade of your knife out two segments or less. If you extend it out any further, the blade may bend and cause poor quality cuts.