

SPARE PARTS LIST

Model # Atd-5812

ITEM	PARTCODE	DESCRIPTION	QTY	ITEM	PARTCODE	DESCRIPTION	QTY
1	649-1-0060-122	hex. bolt	4	41	A57-6-3004-307	release base	1
2	A57-6-1002-105	motor cover	1	42	A57-6-3003-305	release valve	1
3	A17-6-2105-108	cylinder washer	2	43	601-7-0003-009	steel ball	1
4	A17-4-2100-500	air piston assy.	1	44	503-9-0035-100	spring cap	1
5	A57-6-1003-107	cylinder	1	45*	*	spring	1
6	A57-3-1011-108	piston assy.	1	46	644-1-0040-103	hex. bolt	1
7	512-2-0410-017	spring	1	48	A57-6-1603-202	oil tank cover	1
8	A57-6-1014-102	piston cover	1	49*	*	"E" clip	2
9	A57-6-2023-108	bushing	1	50	A57-6-2003-102	foot pedal axle	1
10	573-7-0120-105	back-up ring	1	51	A57-6-5002-105	plug	1
11*	*	"U" cup	1	52	511-7-0156-012	o-ring	1
12	A59-6-1013-105	pump cylinder	1	53	666-5-0160-003	"C" clip	1
13	A57-6-1016-106	washer	1	54	A57-6-3007-105	muffler	1
14	H18-6-8103-104	special washer	1	55*	*	o-ring	2
15	A57-6-1605-105	pad - B	1	56*	*	back-up ring	2
16	511-7-0140-200	o-ring	2	57	A57-6-4002-201	oil outlet valve	1
17	512-2-0092-101	spring	1	58	512-2-0043-108	spring	1
18	649-1-0040-007	hex. bolt	1	59	601-7-0009-001	steel ball	1
19	A57-6-5004-109	air entrance cap	1	60	511-7-0410-102	o-ring	1
20	511-7-0053-104	o-ring	1	61	649-1-0050-055	hex. bolt	6
21	A17-6-1105-105	plastic cap (air end)	1	62	644-1-0060-05311	hex. bolt	1
22	A57-6-5001-103	air entrance base	1	63	503-9-0050-106	spring cap	1
23	A57-6-5003-107	air entrance valve	1	64	601-7-0006-005	steel ball	1
24	511-7-0080-309	o-ring	1	65	512-2-0061-100	spring	1
25	649-1-0050-046	hex. bolt	6	66	A57-6-1001-204	base	1
26	A57-6-2001-108	foot pedal	1	67*	*	special washer	2
27	A57-6-4001-209	oil outlet base	1	68	A59-6-1017-102	high pressure valve	1
28	A17-6-1002-103	muffler	1	69	A17-6-1216-102	needle	1
29	666-5-0250-108	"C" clip	1	70	512-2-0067-010	spring	1
30	A57-6-5005-101	oil stop bar	1	71	A17-5-1603-300	nut	1
31	505-9-0092-308	oil filler plug	1	72	601-7-0008-009	steel ball	1
32	A57-6-3006-103	air outlet base	1	73	A59-6-1015-108	oil entrance valve	1
33*	*	o-ring	1	74	520-8-0134-101	filter	1
34*	*	pad - A	1	75*	*	pad	1
35*	*	o-ring	1	76	A57-6-1601-107	oil tank	1
36	A57-6-3001-112	gasket	1	* Part is not available			
37*	*	release needle	1				
38	552-2-0010-105	spring	1				
39*	*	back-up ring	1				
40*	*	o-ring	1				

