



Model XSJ05Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
1	725129-8	CENTER BLADE	1
2	725130-3	SIDE BLADE	2
3	331738-9	PIVOT BUSH	1
4	331737-1	SPACER BUSH	1
5	264007-2	HEX.LOCK NUT M5	3 PC.
6	331736-3	SHEAR HEAD	1
7	266407-2	HEX.SOCKET BOLT M5X35	3 PC.
8	125354-5	SHEAR HEAD ASS'Y	1
	D10	INC. 1-7	
9	127489-8	ECCENTRIC BEARING ASSEMBLY	1
10	267223-5	FLAT WASHER 10	1 PC.
11	257428-5	SLEEVE 10	1 PC.
12	233929-7	RING SPRING 29	1 PC.
13	310995-2	CHANGE RING	1
14	962105-3	RETAINING RING R-26	1 PC.
15	210059-1	BALL BEARING 6000DDW	1 PC.
16	310993-6	LEVER	1 PC.
17	232390-5	COMPRESSION SPRING 2	2
18	310994-4	BUTTON	1
19	265A48-7	TAPPING SCREW 4X18	3 PC.
20	140R40-5	GEAR HOUSING COMPLETE	1
21	140R42-1	GEAR COMPLETE	1
22	267100-1	FLAT WASHER 6	1 PC.
23	221478-6	GEAR COMPLETE 9-23	1 PC.
24	424928-2	SEAL RING	1 PC.
25	210003-8	BALLBEARING 685ZZ	1 PC.
26	140R41-3	GEAR HOUSING COVER COMPLETE	1
27	961005-4	RETAINING RING S-9	1 PC.
28	211491-2	BALL BEARING 609DDW	1 PC.
29	519424-4	ROTOR ASS'Y	1 PC.
	D10	INC. 27,28,30	
30	210039-7	BALL BEARING 695DDW	1 PC.
31	629489-9	STATOR	1
32	266490-9	TAPPING SCREW PT 2X6	3 PC.
33	620B89-0	CONTROLLER	1
34	857A93-2	XSJ05 NAME PLATE	1
35	266130-9	TAPPING SCREW BIND PT 3X16	8 PC.
36	191K66-8	HOUSING L/R SET	1
	C10	263005-3 RUBBER PIN 6	2 PC.
	C20	252126-6 HEX. LOCK NUT M4-7	2 PC.
	C30	817D86-9 CAUTION LABEL	1 PC.
	D10	INC. 39	
37	412330-1	CHANGE LEVER	1
38	651485-9	SWITCH C3JW-4BM	1
39	191K66-8	HOUSING L/R SET	1
	C10	263005-3 RUBBER PIN 6	2 PC.
	C20	252126-6 HEX. LOCK NUT M4-7	2 PC.
	C30	817D86-9 CAUTION LABEL	1 PC.
	D10	INC. 36	

40	412332-7	SWITCH PLATE	1
41	643860-3	TERMINAL	1 PC.
42	857A97-4	XSJ05 SERIAL NO.LABEL	1
43	267047-9	FLAT WASHER 10	1
44	257852-2	RING 10	1
A01	266622-8	TRUSS HEAD SCREW M4X12	1 PC.
A02	346449-3	HOOK	1 PC.
A03	783215-1	HEX. WRENCH 5/32"	1 PC.