



Air Regulator with Gauge and Valve

Order No. **130516** Model No. **130516**

Order No. **130093** Model No. **HAR-600**


Air Regulator

Order No. **192242** Model No. **HAR-511**

Order No. **130100** Model No. **HAR-520**



130516
Inlet 1/2" NPT (F)
Outlet 1/2" NPT (F)



HAR-600
Inlet 3/8" NPT
Outlet 1/4" NPT (3 ea.)



HAR-511
Inlet 3/8" NPT (F)
Outlet 1/4" NPT (F)



HAR-520
Inlet 3/8" NPT (F)
Outlet 1/4" NPT (F)

Air Regulators

Order No. Model No. Description

130516 75 CFM air regulator, gauge and valve (regulator available separately as 130521)

130093 HAR-600 60 CFM air regulator, gauge and valve (regulator available separately as HAR-507)


192242 HAR-511 60 CFM air regulator — Flow through regulator for pressure tanks

130100 HAR-520 50 CFM air regulator - non-relieving (purchase GA-375 gauge separately)

For Precise Control of Air Delivery

Refer to Service Bulletins SI-6-18-10 and SB-6-147 and Part Sheet 77-2781

130516




Ref. No.	Model No.	Description	Ind. Parts Req.
1	130521	Regulator Kit	1
2	VA-594	Shut-off Valve	1
3	GA-288	Gauge	1

*Lightly grease with enclosed lubricant


Handtight plus 1/4 turn

130100 (HAR-520)



Ref. No.	Model No.	Description	Ind. Parts Req.
1	HAR-520	Regulator Kit	1
7	KK-5088	Repair Kit	1


192242 (HAR-511)



Ref. No.	Model No.	Description	Ind. Parts Req.
1	—	#10-32x9/16 Fillister Hd. Screw	6
2	HAR-14	Cover	1
3	—	Spring Button	1
4	—	Diaphragm Spring	1
5	—	Body	1
6	—	Pipe Plug 1/4" NPT(M)	1
7	—	Bottom Plug	1
●8	—	Diaphragm Assy.	1
●9	—	O-Ring	1
●10	—	Valve	1
●11	—	O-Ring	1
●12	—	Spring	1
●13	—	O-Ring	1


● Available only as part of KK-4977 Repair Kit; order separately.

130093 (HAR-600)



Ref. No.	Model No.	Description	Ind. Parts Req.
1	HAR-507*	Regulator	1
2	GA-288	Gauge	1
3	—	1/4" NPT Street Elbow	1
4	VA-542	Ball Valve	1
5	—	1.4" NPT Plug	1

*HAR-507 Regulator



Ref. No.	Model No.	Description	Ind. Parts Req.
1	—	#10-32x9/16 Fillister Hd. Screw	6
2	HAR-14	Cover	1
3	—	Spring Button	1
4	—	Diaphragm Spring	1
5	—	Body	1
6	—	Pipe Plug 1/4" NPT(M)	1
7	KK-4977	Repair Kit (incl. # 8-13)	1
8	—	Diaphragm Assy.	1
9	—	O-Ring	1
10	—	Valve	1
11	—	O-Ring	1
12	—	Spring	1
13	—	O-Ring	1
14	—	Bottom Plug	1